



# LAUNDRY INSTRUCTIONS

LAMINATED/VINYL PLACEMATS & MATTRESS PADS

PERMALUX® FABRIC SOIL RELEASE COMBINED WITH RIEGEL'S PROPRIETARY STAIN RELEASE FINISH WASHES OUT THE MOST STUBBORN FOOD STAINS.

## WASHING AND DRYING INSTRUCTIONS

### **LAMINATED**

#### **WASHING:**

LOAD WASHER ACCORDING TO EQUIPMENT MANUFACTURER'S SPECIFICATIONS. AFTER WARM FLUSH, WASH ON POLYESTER/COTTON CYCLE AT 160° F (61° C). RINSE AT PROGRESSIVELY LOWER TEMPERATURES. IF STAINS REMAIN AFTER ONE WASH, ADD ONE CUP OF LIQUID CHLORING BLEACH TO 20 GALLONS OF WATER DURING LAUNDERING. ADD BLEACH TO WATER BEFORE ADDING PLACEMATS. THIS CONCENTRATION OF BLEACH WILL NOT HARM THE COLORS. AFTER EXTRACTION, MOVE TO DRYER IMMEDIATELY.

#### **DRYING:**

LOAD DRYER 1/3 TO 1/2 OF RATED CAPACITY. DRY AT LEAST 30° F (17° C) HOTTER THAN WASH TEMPERATURE. MAINTAIN COOLING CYCLE AT 100° F (38° C). REMOVE IMMEDIATELY AT THE END OF THE WASH CYCLE.

WASH ALL PLACEMATS PRIOR TO PUTTING INTO SERVICE.

IF BUBBLING OCCURS, IRONING WILL RE-BOND THE FABRIC

### **VINYL**

#### **Cleaning:**

- To clean your Riegel Vinyl Placemats, lay them on a clean, flat surface and wipe with soap and warm water, using a soft cloth or sponge.
- More stubborn stains may require the use of a soft-bristled brush and a bleach-based cleanser.
- After cleaning, rinse with plenty of warm water and allow to dry.

#### **General Care:**

- It is not recommended to clean vinyl placemats using a machine washer or dishwasher.
- Antibacterial cleaners are safe to use on the vinyl placemats. Rinse thoroughly after application.
- Do not fold the placemats for storage, or allow to crease.
- Do not allow very hot items to be placed on the vinyl placemat.
- Although they are resistant to staining, sauces containing tomatoes and peppers may permanently stain the vinyl placemat if a spill is not cleaned promptly.



# LAUNDRY INSTRUCTIONS

LAMINATED/VINYL PLACEMATS & MATTRESS PADS

## MATTRESS PADS WASH FORUMLA

Operation	Water Level	Water Temp °F	Time	Drain Time
Flush	High	Cold/98	2 MIN.	2 MIN.
Break Suds	Low	Hot/150	6 MIN.	2 MIN.
Alkali Detergent - pH = 11/12				
Rinse	High	Hot/150	3 MIN.	2 MIN.
Bleach Suds	Low	Hot/150	8 MIN.	2 MIN.
Bleach Detergent - pH = 9.8 - 10.8				
Rinse	High	Hot/150	2 MIN.	2 MIN.
Rinse	High	Split/125	2 MIN.	2 MIN.
Rinse	High	Cold/98	2 MIN.	2 MIN.
Sour	Low	Cold/98	4 MIN.	2 MIN.
pH = 5.5 - 7.0				